

AVR-X7200W(A) DTS:X UPDATE

Please note that we are very happy to announce that the **free of charge DTS:X update** for the AVR-X7200W and AVR-X7200WA is available for download.

This update introduces some changes to your system that we want you to be aware before you update the unit since it may affect daily usage.

The following features are added:

- DTS:X decoding
- DTS Neural:X upmixing to enjoy non DTS:X content (in PCM or DTS format) using the full DTS:X speaker configuration

With added DTS:X decoding and DTS Neural:X upmixing capability, following changes will happen to your receivers:

- DTS Neo:X will be replaced by DTS Neural:X
- Dolby Surround mode usage will be limited to PCM and Dolby content

You can also take a look in the modified user manuals for the products:

- [Web manual for AVR-X7200W with DTS:X](#)
- [Web manual for AVR-X7200WA with DTS:X](#)

AVR-X7200W(A) DTS:X UPDATE


To update your unit, follow the below steps:

1. Press the SETUP button on the Remote Control
2. Select General > Firmware > Update
3. Select Update Now

***Note on Auro-3D upgraded units:**

If you have an Auro-3D upgraded unit, DTS:X firmware update won't effect this. However we will add more flexibility to the speaker setup and after the update you will be able to use the following speaker configuration to enjoy all 3D sound formats (Dolby Atmos, DTS:X and Auro-3D) by one speaker layout with 4 height speakers:

Front (FL/FR)
Center (C)
Surround (SL/SR)
Front Height (FHL/FHR)
Rear Height (RHL/RHR)
Subwoofer (SW)






AGGIORNAMENTO FIRMWARE DTS:X PER QUESTA UNITÀ

Per utilizzare DTS:X su questa unità occorre procedere a un aggiornamento del firmware.


Modalità di aggiornamento

1. Quando l'aggiornamento del firmware DTS:X sarà disponibile, dopo l'accensione dell'unità e l'attivazione della connessione Internet, sulla TV apparirà la schermata seguente.



2. Selezionare sul display dello schermo una delle seguenti opzioni.

- ① **Aggiorna**
Avviare il processo di aggiornamento.
- ② **Aggiorna più tardi**
Apparirà la seguente schermata.



- ②-1. **Ricordami più tardi**
Chiederà se si desidera effettuare l'aggiornamento alla successiva accensione dell'unità.
- ②-2. **Aggiorna durante lo standby**
Il firmware dell'unità sarà aggiornato al successivo spegnimento dell'unità.

- ③ **Ignora**
Non aggiornare il firmware dell'unità.



È anche possibile aggiornare il firmware dell'unità procedendo dal menu di configurazione.

1. Premere il pulsante SETUP sul telecomando.
2. Selezionare Generale → Firmware → Aggiornamento
3. Selezionare Aggiornamento.