

AVR-X7200W(A) DTS:X UPDATE

Please note that we are very happy to announce that the **free of charge DTS:X update** for the AVR-X7200W and AVR-X7200WA is available for download.

This update introduces some changes to your system that we want you to be aware before you update the unit since it may affect daily usage.

The following features are added:

- DTS:X decoding
- DTS Neural:X upmixing to enjoy non DTS:X content (in PCM or DTS format) using the full DTS:X speaker configuration

With added DTS:X decoding and DTS Neural:X upmixing capability, following changes will happen to your receivers:

- DTS Neo:X will be replaced by DTS Neural:X
- Dolby Surround mode usage will be limited to PCM and Dolby content

You can also take a look in the modified user manuals for the products:

- [Web manual for AVR-X7200W with DTS:X](#)
- [Web manual for AVR-X7200WA with DTS:X](#)

AVR-X7200W(A) DTS:X UPDATE


To update your unit, follow the below steps:

1. Press the SETUP button on the Remote Control
2. Select General > Firmware > Update
3. Select Update Now

***Note on Auro-3D upgraded units:**

If you have an Auro-3D upgraded unit, DTS:X firmware update won't effect this. However we will add more flexibility to the speaker setup and after the update you will be able to use the following speaker configuration to enjoy all 3D sound formats (Dolby Atmos, DTS:X and Auro-3D) by one speaker layout with 4 height speakers:

Front (FL/FR)
Center (C)
Surround (SL/SR)
Front Height (FHL/FHR)
Rear Height (RHL/RHR)
Subwoofer (SW)






DTS:X FIRMWAREUPPDATERING FÖR DENNA ENHET

Denna enhet behöver en firmwareuppdatering för att kunna njuta av DTS:X.


Uppdatera så här

1. När DTS:X firmwareuppdateringen är tillgänglig visas följande skärm på din TV när du sätter på enheten och ansluter till internet.



2. Välj ett av följande alternativ från skärmen som visas.

- ① Uppdatera nu
Starta uppdateringsprocessen.
- ② Uppdatera senare
Följande skärm visas.



- ②-1. Påminn mig senare
Frågar dig om du vill uppdatera nästa gång du sätter på enheten.
- ②-2. Uppdatera under standby
Enhetsens firmware uppdaterar nästa gång du stänger av den.

- ③ Ignorera
Uppdatera inte firmware på din enhet.



Du kan även uppdatera firmware på enheten från installationsmenyn.

1. Tryck på SETUP-knappen på fjärrkontrollen.
2. Välj Allmänt → Fast programvara → Uppdatera
3. Välj Uppdatera.