

AVR-X7200W(A) DTS:X UPDATE

Please note that we are very happy to announce that the **free of charge DTS:X update** for the AVR-X7200W and AVR-X7200WA is available for download.

This update introduces some changes to your system that we want you to be aware before you update the unit since it may affect daily usage.

The following features are added:

- DTS:X decoding
- DTS Neural:X upmixing to enjoy non DTS:X content (in PCM or DTS format) using the full DTS:X speaker configuration

With added DTS:X decoding and DTS Neural:X upmixing capability, following changes will happen to your receivers:

- DTS Neo:X will be replaced by DTS Neural:X
- Dolby Surround mode usage will be limited to PCM and Dolby content

You can also take a look in the modified user manuals for the products:

- [Web manual for AVR-X7200W with DTS:X](#)
- [Web manual for AVR-X7200WA with DTS:X](#)

AVR-X7200W(A) DTS:X UPDATE


To update your unit, follow the below steps:

1. Press the SETUP button on the Remote Control
2. Select General > Firmware > Update
3. Select Update Now

***Note on Auro-3D upgraded units:**

If you have an Auro-3D upgraded unit, DTS:X firmware update won't effect this. However we will add more flexibility to the speaker setup and after the update you will be able to use the following speaker configuration to enjoy all 3D sound formats (Dolby Atmos, DTS:X and Auro-3D) by one speaker layout with 4 height speakers:

Front (FL/FR)
Center (C)
Surround (SL/SR)
Front Height (FHL/FHR)
Rear Height (RHL/RHR)
Subwoofer (SW)






DTS:X AKTUALIZACJA OPROGRAMOWANIA WBUDOWANEGO DLA TEGO URZĄDZENIA

To urządzenie wymaga aktualizacji oprogramowania wbudowanego do obsługi DTS:X.


Metoda aktualizacji

1. Gdy dostępna jest aktualizacja oprogramowania wbudowanego urządzenia, po włączeniu urządzenia i uzyskaniu połączenia z Internetem na ekranie telewizora zostanie wyświetlony następujący ekran.



2. Na wyświetlanym ekranie należy wybrać jedną z następujących opcji.

- ① Aktualizuj teraz
Rozpoczyna proces aktualizacji.
- ② Aktualizuj później
Zostanie wyświetlony następujący ekran.



- ②-1. Przypomnij mi później
Przypomnienie o aktualizacji zostanie wyświetlone po kolejnym włączeniu urządzenia.
- ②-2. Aktual. w trybie czuwania
Oprogramowanie wbudowane urządzenia zostanie zaktualizowane po jego wyłączeniu.

- ③ Ignoruj
Nie aktualizuje oprogramowania wbudowanego urządzenia.



Oprogramowanie wbudowane urządzenia można również zaktualizować w menu konfiguracji.

1. Nacisnąć przycisk SETUP na Pilocie.
2. Wybrać Ogólne → Oprogramowanie → Aktualizacja
3. Wybrać Aktualizacja.